

DECATHLON

單車組裝指南

BIKE ASSEMBLY MANUAL

安裝腳踏

安裝腳踏前分清楚驅動側與非驅動側，「L」表示非驅動側「R」則表示驅動側，先在腳踏螺紋處塗上適量雪油。在驅動側用手將R的腳踏順時針方向初步上緊，確保腳踏螺紋與曲柄咬合位置正確，最後用15MM板手上緊。在非驅動側的上緊方向則以逆時針方向上緊腳踏。

車胎打氣

留意車胎上的建議氣壓，用打氣筒為車胎打氣。

把手

兒童單車 城市單車 摺合單車

將把手組插入轉向管。根據使用者的身高調節把手組的高度，確保不要超過最小插入標記或止擋位置。最後，將車把和前輪對準，並在把手組頂部用6mm六角頭擰緊螺絲。(圖1)

山地單車 公路單車

(RC500和RC520除外)

1. 扭鬆螺絲 (B)，然後將車把和前輪對準。(圖2)
2. 對齊後扭緊螺絲 (B)。
3. 鬆開面板螺絲 (C)。
4. 半扭緊螺絲 (C)，確保頂部和底部的間隙相等。
5. 將自行車放在地面上，並確保龍頭位於把手的中心，並調節把手的角度。
6. 最後扭緊螺絲 (C)。確保頂部和底部的間隙相等。

公路單車 RC500和RC520

1. 扭鬆螺絲 (B)，然後將車把和前輪對準。(圖3)
2. 對齊後扭緊螺絲 (B)。
3. 鬆開面板螺絲 (C)。
4. 扭緊龍頭螺絲 (C1)，確保頂部緊貼沒有間隙，再半扭緊螺絲 (C2)。
5. 將自行車放在地面上，並確保龍頭位於把手的中心，並調節把手的角度。
6. 最後根據建議扭力值扭緊螺絲 (C2)。




圖1




圖2




圖3

PEDALS

Identify the left and right hand pedals supplied with your bike. There is a L and R marked on each pedal indicating which side of the bicycle it should be mounted. L is non-drive side and R is drive side. Before you install we suggest applying some grease to the thread of pedals. For the drive side or R pedal rotate the pedal by hand into the crank in a clockwise direction. Use a 15mm wrench to tighten the pedal. For the non-drive side or the L pedal, it must be tightened in an anti-clockwise direction.

TIRE PRESSURE

Please check the suggested tyre pressure range marked on the tyre wall and inflate if necessary to within the suggested range. Tyre pumps are supplied separately.

HANDLES BAR

Kids Bike
City Bike
Folding Bike

Insert stem into steerer tube. Adjust height of stem, depending on user height, ensuring that you do not go beyond the minimum insertion marker or as far as the stop. Last you align handlebar and front wheel and tight the screw with 6mm hex at the top of the stem. (Image 1)

Mountain Bikes
Road Bike
(Except RC500 & RC520)

1. Unscrew pinch bolts (B) and align the handle bar and front wheel. (Image 2)
2. Tighten pinch bolts (B) when it is aligned.
3. Unscrew the faceplate bolts(C).
4. Partially tighten the faceplate bolts(C), making sure the gaps are equal on the top and bottom.
5. Set the bike on the ground, and make sure the bar is centered in the stem and adjust bar roll.
6. Tighten the faceplate bolts(C) at last. making sure the gaps are equal on the top and bottom.

Road Bike
RC500 & RC520

1. Unscrew pinch bolts (B) and align the handle bar and front wheel. (Image 3)
2. Tighten pinch bolts (B) when it is aligned.
3. Unscrew the faceplate bolts(C1 and C2) .
4. Partially tighten the faceplate bolts(C) with handlebar. Tighten screws (C1) and make sure there is no gap. Partially tighten screws (C2).
5. Set the bike on the ground, and make sure the bar is centered in the stem and adjust bar roll.
6. Tighten the faceplate bolts(C2) at last and make sure they are tighten in correct torque.




Image 1




Image 2




Image 3



如需更多協助及技術支援，
歡迎致電或 Whatsapp 我們的單車運動大使

For additional technical support, please contact one of our
cycling sport leaders via phone call or WhatsApp

Andy CHAU / Yu WONG / Fish YEE / Kachun LAM
91659226 / 91659224 / 91659132 / 59933727



掃描 QR code
瀏覽更多維修教學
Scan QR code for
more maintenance videos